

32 30 20 24 22




FIGURE 1

34




FIGURE 2




FIGURE 3




FIGURE 4




Figure 5




FIGURE 6A




FIGURE 6B

C[1:0] denote channel band (low, mid, or high)
 P[2:0] denote power level (0 through 7)




FIGURE 7




FIGURE 8